

# DYNACOAT

## KORAKI BRUŠENJA

		POPRAVILO	NOVI DELI	
1	<p>Odstranjevanje barve / brušenje kovinske površine</p> <p>Odstranjevanje prask brušenja P120 pred nanosom kita</p>	<p>Suho: P120 - P220</p> <p>3M CUBITRON P240</p>	<p>Suho: P320</p>	
2	Brušenje kita	<p>Suho: P120 - P220</p> <p>3M CUBITRON P240</p>		
3	Brušenje okolice	<p>Suho: P320 - P400</p>		
4	Brušenje fillerja	<p>Suho: P400 - P600</p> <p>Mokro: P800 - P1000</p>		
5	Končni korak brušenja za bazo ali akril	<p>Suho: P400 - P600</p> <p>Mokro: P800 - P1000</p>		